


PARTS LIST 5" AND 6" (125 MM AND 150 MM)



ITEM	DESCRIPTION	QTY	PART NO
	Piston Kit		75-1110
	Above Kit consists of:		
1	Piston	1	75-0570
2	Piston Seal	1	75-0602
3	Adapter O-ring, Inner	1	75-0605
4	Adapter O-ring, Outer	1	75-0606
	Gasket Kit		75-1111
	Above Kit consists of:		
3	Adapter O-ring, Inner	1	75-0605
4	Adapter O-ring, Outer	1	75-0606
7	Seat Seal O-ring	1	75-0613
10	Back-up Washer	1	50-0324
11	Stem O-ring	1	50-0293
12	Stem Washer	1	50-0299
13	Stem Packing	1	50-0290
14	Packing Nut	1	50-0292
15	Seal Cap Gasket	1	50-0315
16	Manual-Opening Stem Pin	1	75-0607
	Solenoid Tube Gasket	1	70-0301
	Port O-ring and Gasket	3	75-1071

ITEM	DESCRIPTION	QTY	PART NO
	V-Port/Seat Kit 5"		75-1112
	V-Port/Seat Kit 6"		75-1113
	Above Kits consist of:		
5a	V-Port/Seat 5"	1	75-0640
5b	V-Port/Seat 6"	1	75-0641
3	Adapter O-ring, Inner	1	75-0605
4	Adapter O-ring, Outer	1	75-0606
7	Seat Seal O-ring	1	75-0613
8	Seat Screw (1/4"-20 x 1/2")	1	75-0220
9	Closing Spring	1	75-0601
6	Seat Ring	1	75-0558
17	Manual-Opening Stem	1	75-0581
18	Seal Cap	1	50-0304
19a	Adapter, 1 Port	1	75-0554
19b	Adapter (1 Port) with Plugged Access Holes for Multiple Pilots	1	75-0720
20	Gauge Port Plug	1	75-0189
21	Adapter Bolts	8	75-0604
22a	Body, 5"	1	75-0542
22b	Body, 6"	1	75-0541